

Concrete Rehabilitation Process

The photos are of work done on a previous contract. They describe the work/process needed for rehabilitating the unsound concrete.

Description of work

Remove spalls (concrete that is coming loose)

Saw cut concrete area to a rectangular shape and chip to board form







Expose steel reinforcing bars

Steel is then pinned and rewired just before patching





Concrete is mixed to resemble color and texture and placed on patch area to complete work as shown on the far right photo





